

## How to mount the P110 onto the Brauner elastic suspension

- 1) Hook the left hooks of P110 on the left vertical bar of the Brauner elastic suspension
- 2) Squeeze the arms of Brauner elastic suspension together about 2 mm.
- 3) Slide over the rounded part of P110. This must be done with little force.
- 4) The P110 is in place.

